

**ELISE**  
44.01


# Service Parts List **ELISE**



## Function Code 44.01 Fuel Tanks, Filler

<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
01	Fuel Tank			A117L0052H	1
02	Hose, fuel filler			A117L0044F	1
03	Filler Neck				1
04	Hose, fuel breather			A117L0045F	1
05	Fuel Filler Cap, locking	Includes lock barrel		A117L0025J	1
05a	Fuel Filler Cap	Cap only		A117L6058F	1
06	Ring, fuel filler cap to clamshell			B117L0037F	1
07	Setscrew No 6 x 1/2", filler neck to body				8
08	Gasket, clamping ring			B117L0021F	1
09	Clamping Ring, filler to clamshell				1
10	Screw, ring to filler neck				2
11	Hose Clip, breather hose			A117W6677F	4
12	Hose Clip, filler hose, upper			A117W6679F	2
13	Hose Clip, filler hose, lower			A117W6678F	2
14	Earth Braid			A079M4049F	1
15	Nut, braid to filler neck				2
16	Washer, flat				2
17	Setscrew, M8 x 25, tank to chassis			A075W1039Z	4

**ELISE**




**ELISE**  
44.01

---

**Function Code 44.01 Fuel Tanks, Filler**

<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
18	Washer, spring, M8, tank to chassis			A075W4036Z	4
19	Washer, flat, M8, tank to chassis			A075W4019Z	4

---




**ELISE**  
44.03

# Service Parts List **ELISE**



## Function Code 44.03 Fuel Pump; Filter, Pipes

<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
01	Fuel Pump and Sender Unit			A116L6001L	1
02	Circlip, pump to tank				1
03	Access Panel, fuel tank			A117L0042F	1
04	Screw, access cover			A111W7117F	4
05	Grommet			A117L6027F	2
06	'O' Ring, fuel pump to tank			A111L6008F	1
07	Fuel Pipe Assembly, feed, pump to filter			A117L0006F	1
08	Adaptor Pipe, filter inlet to feed hose			A111L6006F	1
09	Fuel Pipe Assembly , feed, filter to engine			A117L0012F	1
10	Fuel Pipe Assembly, return			A117L0008F	1
11	Cable Tie, quick connect retention			A075W6038F	2
12	Fuel Filter Housing Assembly	Includes pipe item 14		A111L6002F	1
13	Fuel Filter Element			A340L6038S	1
14	Adaptor Pipe, filter outlet to feed hose			A111L6038S	1
15	Bracket, filter mounting			A117L0003F	1
16	Setscrew, M6 x 18, cap hd., filter assy to bracket				2
17	Washer, flat, M6			A075W4015Z	4
18	Nyloc Nut, M6			A075W3009Z	2



**ELISE**  
44.05

# Service Parts List

# ELISE



## Function Code 44.05 Charcoal Canister & Evaporative Loss System.

<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
01	Charcoal Canister Assembly	Includes pipes & fixings		A117L0029H	1
02	Roll Over Valve			A117L6039H	1
03	Mounting Clamp, roll over valve			A111L6012H	1
04	Setscrew, M6 x 12, roll over valve fix.			A075W1027Z	1
05	Washer, M5, roll over valve fix.			A075W4011Z	2
06	Nyloc Nut, M6, roll over valve fix			A907E6285F	1
07	Hose, roll over valve to filler neck			A117L6015H	1
08	Hose Clip			A117L6024	1
09	Hose Clip				2
10	Bracket, charcoal canister			A111L6009F	1
11	Pop Rivet, bracket to bulkhead				1
12	Clip, four pipe retention				3
13	Clip, two pipe retention				5

# ELISE