

ELISE
14.01


Service Parts List **ELISE**



Function Code 14.01 Pedal Box, Pedals, Throttle Cable

<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
01	Throttle Pedal			C111J0018F	1
01a	Throttle Pedal Assembly			C111J0016J	1
02	Pad, throttle pedal			A111J0081F	1
03	Setscrew, M5 x 16, pad to arm retention			A075W1085F	1
04	Washer, M5 x 10 x 1.0, pad to arm retention			A075W4011Z	2
05	Nyloc Nut, M5, pad to arm retention			A075W3008Z	1
06	Bearing, pedal pivots			A111J6018F	6
07	Thrust Washer, pedal pivots			A111J6019F	5
08	Brake Pedal			B111J0069F	1
08a	Brake Pedal Assembly			B111J0070F	1
09	Pad, brake & clutch pedals			C111J0019F	2
10	Clutch Pedal			C111J0017F	1
11	Push Rod, brake master cylinder			A111J0041F	1
12	Push Rod, clutch master cylinder			A111J0042F	1
13	Pop Rivet, 5/32" x 1/2", pad fix.			A075W6068Z	2
14	Trunnion, clutch/brake pedal			A111J0155F	2
15	Grubscrew, M6 x 6, push rod locking			A111W7147F	2
16	Driver Footrest, RHD			A111A0103F	1

ELISE




ELISE

14.01

Function Code 14.01 Pedal Box, Pedals, Throttle Cable


<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
16a	Driver Footrest, LHD			A111A0104F	1
17	Screw, M6 x 16, pozi, footrest fix.			A076W5090F	3
18	Washer, shakeproof, M6, footrest fix.			A075W4046Z	3
19	Locknut, M6, footrest fix.			A100W3108F	3
20	Pedal Shaft			B111J0038F	1
21	Nyloc Nut, , M6, shaft fix.			A075W3009Z	2
22	Washer, flat, M6, shaft fix.			A075W4013Z	2
23	Screw, M6 x 35, hex. hd., shaft fix.			A075W1033Z	2
24	Grip-Lock, self adhesive, hook			A111V6020V	0.6M
25	Grip-Lok, self adhesive, loop			A111V6019V	0.6M
26	Passenger Footrest Assembly, RHD			B111A0101J	1
26a	Passenger Footrest Assembly, LHD			B111A0102J	1
27	Foam Seal, 25 x 12.5			A082U6065V	As req.
28	Side plate, pedal box, LH			B111J0033F	1
29	Side plate, pedal box, RH			B111J0034F	1
30	Screw, M6 x 20, hex. hd., side plate fix.			A111W1155F	6
31	Washer, spring, M6			A075W4035Z	6
32	Clip, throttle cable to manifold fix.			A082W6370F	1
33	Clip, throttle cable to canister pipe fix.			A089W6268F	1
34	'P' Clip, throttle cable to sump			A111W6611F	1
35	Washer, shakeproof, M8, 'P' clip to sump			A075W4048Z	1



ELISE
14.01

Function Code 14.01 Pedal Box, Pedals, Throttle Cable


<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
36	Setscrew, M8 x 20, 'P' clip to sump			A075W1038Z	1
37	Tie Wrap, throttle cable fix.			A082W6324F	1
38	Throttle Cable			A117J0061F	1
39	Collar, brake light switch fix.			A089M6020F	1
40	Brake Light Switch			A089M6019F	1
41	Bush, nylon, relay lever			A111J6017J	1
42	Nut, M4, nyloc			A075W3049F	1
43	Thrust Washer, nylon, relay lever			A111J6016F	8
44	Relay Lever, throttle linkage			B111J0045F	1
45	Nut, nyloc, M5			A100W3113F	2
46	Slider Button, relay lever			A111J6020F	1
47	Base Plate, relay lever, RHD			C111J0048F	1
47a	Base Plate, relay lever, LHD			C111J0047F	1
48	Washer, shakeproof, M5, base plate fix			A075W4054Z	2
49	Screw, M5 x 10, pozi, base plate fix.			A082W5097F	2
50	Screw, M4 x 16, pozi, swivel fix.			A100W5133F	2
51	Swivel, throttle linkage			A111J0043F	1
52	Pedal Box Extrusion			D111J0021F	1
53	Nut, M5, nyloc			A075W3008Z	1
54	Washer, flat, M5 x 10 x 0.8,			A111W4168F	1
55	Screw, M5 x 12, button hd.			A111W7138F	1



ELISE
14.01

Function Code 14.01 Pedal Box, Pedals, Throttle Cable

<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
56	Setscrew, M6 x 35, throttle pedal stop			A075W1033Z	1
57	Nyloc Nut, M6, throttle pedal stop			A082W3085F	1
58	Pulsert, M6 x 1.0			A079W6156F	1
59	Nut Plate, pedal box			A111J0083F	1
60	Setscrew, M5 x 12, hex. hd.			A075W1021Z	1
61	Blanking Plug			A111J6020F	2
62	Link, throttle spring, RHD			A111J0096F	1
62a	Link, throttle spring, LHD			A111J0097F	1
63	Throttle Return Spring			A075J6029Z	1
64	Pull Rod , throttle linkage	Rod only		A111J0044F	1
65	Ball Joint, pull rod			A111J6015F	2
66	Locknut, M5, ball joint/pull rod			A082W3088F	2
67	Bracket, throttle pedal to pull rod			B111J0046F	1
68	Pop Rivet, 3/16", bracket to throttle pedal			A075W6087Z	1
69	Nyloc Nut, M5, throttle pedal link fix.			A100W3113F	2
70	Bush, synthetic, pedal trunnions			A111J6036F	4
71	Grease, molycote DC33 medium, pedal bush lube	Not illustrated		A111F6016V	As req.




ELISE
14.05

Service Parts List **ELISE**



Function Code 14.05 Fascia Structure & Supporting Hardware


<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
01	Capping Panel, fascia top			A117U0014F	1
02	Fascia Top Panel, black, RHD		Standard	C117U0090F	1
02a	Fascia Top Panel, black, LHD		Standard	C117U0089F	1
02b	Fascia Top Panel, black alcantara, RHD		Race Tech Pack	C117U0256F	1
02c	Fascia Top Panel, black alcantara, LHD		Race Tech Pack	C117U0257F	1
02d	Fascia Top Panel, black leather, RHD		Sports Tourer Pack	C117U0094F	1
02e	Fascia Top Panel, black leather, LHD		Sports Tourer Pack	C117U0093F	1
03	Trim Panel, lamp recess, RHD			B117U0142F	1
03a	Trim Panel, lamp recess, LHD			B117U0015F	
04	Dash Panel Upper, passenger, RHD			B117U0020F	1
04a	Dash Panel Upper, passenger, LHD			B117U0019F	1
05	Dash Panel Upper, driver, RHD			B117U0018F	1
05a	Dash Panel Upper, driver, LHD			B117U0017F	1
06	Dash Panel Lower/Stowage Shelf, RHD			C117U0032F	1
06a	Dash Panel Lower/Stowage Shelf, LHD			C117U0031F	1
07	Bracket, dash support, passenger's side			B117U0022F	1
08	Bracket, interior lamp fix.			A117U0149F	1
09	Bracket, dash suport, driver's side			A116U0096F	1



ELISE
14.05

Function Code 14.05 Fascia Structure & Supporting Hardware


<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
10	Divider, stowage shelf, RH			B117U0027F	1
11	Tray, stowage shelf			B117U0026F	1
12	Blanking Panel, radio aperture			C117U0122F	1
13	Edging Strip, radio protection	Fitted to item 7			1
14	Divider, alloy, stowage shelf		Optional/accessory		As req.
15	Closing Panel, stowage shelf, LH			B117U0028F	1
16	Pop Rivet				2
17	Screw, hex. hd.				4
18	Washer, spring				4
19	Washer, flat				4
20	Screw, pan hd., pozi.				4
21	Screw, pan hd., pozi., brackets to chassis				3
22	Plastic Fastener				2
23	Pop Rivet				2
24	Washer, flat				2
25	Screw, pan hd., pozi., trim panel fix.				4
26	Column Shroud, upper			C007U0024F	1
27	Column Shroud, lower			C117U0025F	1
28	Screw, csk. hd., shroud to brackets				3
29	Spire Nut			A075W5014Z	2
30	Screw, brackets to column				3



ELISE
14.05

Function Code 14.05 Fascia Structure & Supporting Hardware

<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
31	Washer, flat				3
32	Bracket, shroud to column front				1
33	Bracket, shroud to column rear				1
34	Spire Nut				3
35	Screw, No.6 x 0.5", button hd.			A075W5012F	2
36	Finisher Ring, steering lock to shroud				2
37	Screw, ejot			A117F6001F	2
38	Washer, flat, m4 x 9 x 0.8			A082W4136F	2
39	Easy Fastener, ejot			A117F6000F	2




ELISE
14.10

Service Parts List **ELISE**



Function Code 14.10 Instrument Cowling

<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
01	Instrument Cowling			B117U0040F	1
02	Bracket, instrument mounting, RH			C111U0156F	1
03	Bracket, instrument mounting, LH			C111U0155F	1
04	Nut, M4	Instrument pack to brackets		A075W3019F	4
05	Washer, flat, M4 x 9 x 0 8	Instrument pack to brackets		A082W4099F	4
06	Screw, M6 x 15, hex. hd.	Brackets to dash		A100A6024F	2



ELISE

15.05

Service Parts List **ELISE**



Function Code 15.05 Interior Driving Mirror

<u>Dep</u>	<u>Part Description</u>	<u>Remarks</u>	<u>Option</u>	<u>Part Number</u>	<u>Qty</u>
01	Mirror, interior rear view			A111U6001F	1
02	Mounting Plinth, interior mirror			A111U6026F	1
03	Adhesive Kit, mirror mounting plinth	Not illustrated		A100B6230S	1